



# Installation Instructions

**Toe Shift Control Conversion  
P/N RSC1070TP**

## **Forward Control Removal and Disassembly**

1. Remove the shift side forward control from the bike.
2. Choose one of the tips from the heel-toe lever to use on the new toe lever.
3. Remove the rubbers from the tip.
4. Using a propane torch, warm the Allen-head bolt to approximately 250 degrees. This will help soften the Loctite®.
5. Remove the Allen-head bolt from the tip, being careful not to scratch the control. Gripping the tip in a vice equipped with soft jaws may help.
6. Remove the two Allen-head bolts from the shift pivot assembly.

## **Forward Control Assembly and Installation**

1. Reassemble the forward control and bolt it back onto the bike, using "RED" Loctite® on every bolt.

*Note: The use of red Loctite ® is essential, as the vibrations encountered on a motorcycle will loosen bolts over time if they are not secured with Loctite®.*